


NOTE:

1. APPROVED PRESSURE VACUUM BREAKER ASSEMBLY MUST BE INSTALLED VERTICALLY, 1" MIN. ABOVE FLOOD LEVEL IF FACTORY MOUNTED OR 6" MIN. ABOVE FLOOD LEVEL FOR GENERAL PLUMBING.
2. DESIGNED FOR BACK SIPHONAGE ONLY, NOT FOR BACK PRESSURE.
3. THOROUGHLY FLUSH LINES PRIOR TO INSTALLATION OF BACKFLOW PREVENTER.
4. IF A SVBA IS INSTALLED INDOORS, CONSIDERATION MUST BE GIVEN TO WATER LEAKAGE IF THE BACKFLOW PREVENTER FAILS (EXCESSIVE WATER SPILLAGE)
5. DO NOT INSTALL IN AN AREA SUBJECT TO FLOODING.
6. MUST BE PROTECTED FROM FREEZING CONDITIONS.
7. THE BACKFLOW ASSEMBLY SHALL BE A STATE APPROVED MODEL.
8. A PLUMBING PERMIT IS REQUIRED— PLEASE CONTACT LOCAL PLUMBING PERMIT CENTER.
9. MUST BE TESTED AFTER INSTALLATION AND YEARLY THEREAFTER BY WASHINGTON STATE CERTIFIED BACKFLOW ASSEMBLY TESTER. TEST RESULTS SHALL BE SENT TO THE CITY OF EDMONDS PUBLIC WORKS.

**(ABOVE GROUND INSTALLATION ONLY)**



CITY OF EDMONDS

REVISIONS

APPROVED BY	DATE

STANDARD DETAIL

**SPILL-RESISTANT PRESSURE VACUUM BREAKER (SVBA)**

DATE 6/16/03

SCALE NTS

DWG NO. **E7.14**